

Treatment diagram

## Mitsubishi Lancer Stationcar Model 2004

Floor level





Engine compartment: Cowl: Treat via 3 drilled holes. See fig. 4 for correct drilling level. Treatment on top of longitudinal member, behind spring struts, under air filter, battery box and fuse box. See fig 3 for correct treatment.

Bonnet lid: Treat via existing holes and gaps.



Engine compartement sectional view, right side: Fig. for correct treatment.



Cowl: Fig: drilling at correct level.



A-pillar: Drill top hole above door hinge. Lower drill hole is drilled below door hinge.



Front door: Treat via 2 drilled holes. Lower drill hole: Drill level just above existing plug. Treat-ment via existing plugged hole and drain holes i bottom.



B-pillar: Treat via 1 drilled hole and existing plugged hole. Drill level with centre line for door hinges.



Rear wing: Fig. for correct treatment.



Treat via existing plugged holes.



Drill and plug hole

Drill hole







Rear door: Treat via 2 drilled holes. Lower drill hole: Drill hole level with nethermost screw for door fastenings. Treatment via existing plugged hole and drain holes i bottom.



C-pillar: Treat via 1 drilled hole and existing

Tailgate side: 3 drill holes for correct treatment. (cau-tion when advancing lance).

Treat via existing holes.



Treatment diagram

## Mitsubishi Lancer Stationcar Model 2004













Cross member above rear axle assembly: Treat via existing holes and gaps.





Fig. for correct treatment.





Longitudinal member rear: Treat via existing holes.





U-member behind bumper: Treat via existing holes and gaps.