











CITROËN BERLINGO

1996-

VEHICLE ON THE FLOOR





1. engine bonnet; remove upholstery
2. longitudinal reinforcement in front wings; right; front section
3. front longitudinal members; front section; remove rubber sealing
4. paravent plaat losmaken; spray sparingly
5. longitudinal reinforcement in front wings; left; remove fuse box; drill and plug hole
6. front longitudinal members; rear section; remove rubber sealing
7. crossmember, upper
8. transversal reinforcement at dash panel




9. longitudinal reinforcement in front wings; right; rear section; remove rubber sealing

10. 'A' posts; drill and plug hole
11. front doors; remove upholstery


12. 'B' posts; drill and plug hole



13. rear doors; detach upholstery
14. rear doors; remove grommet
15. rear end of roof; reinforcements
16. 'C' posts
17. rear doors; front section



UNDERSIDE



18. bumper brackets

19. subframe

20. crossmember, lower

21. subframe


22. sills; front section; remove rubber sealing

23. sills; front; remove plug

24. floor panel; reinforcements; front section

25. longitudinal reinforcements of tunnel

26. front wings; remove plastic insert



27. rear longitudinal members; front section

28. crossmember front of fuel tank

29. sills; rear section; remove rubber sealing

30. rear longitudinal members; front section

31. rear longitudinal members; rear section

32. floor panel; reinforcements; rear section

33. crossmember rear of fuel tank

34. crossmember, lower

35. rear wings; remove plastic insert