



# DAEWOO LANOS 1997-


## VEHICLE ON THE FLOOR



1. engine bonnet
2. front wings; rear section; right; remove fuse box
3. vertical reinforcements; dash panel
4. front wings; rear section; left
5. crossmember, upper; radiator!
6. bulkhead; detach panel; do not spray upwards!




7. front doors; rear section; drill and plug hole; loudspeaker!
8. front doors; front section; drill and plug hole; loudspeaker!
9. 'A' posts; drill and plug hole
10. 'B' posts; drill and plug hole; pull out and lock safety belt
11. rear doors; rear section; drill and plug hole
12. rear doors; front section; drill and plug hole



13. tailgate; rear section; detach panel
14. tailgate; front section; detach panel
15. top; reinforcements; detach panel
16. 'C' posts; drill and plug hole
17. rear wings; left; remove cover
18. 'C' posts; left
19. rear wings; right; remove cover
20. 'C' posts; right




## UNDERSIDE



21. crossmember, lower  
 22. front longitudinal members; front section  
 23. vertical reinforcements  
 24. front longitudinal members; rear section

25. suspension arms  
 26. sills; front section; remove plug  
 27. reinforcements at front end of floor panel  
 28. longitudinal member; floor panel; front section

29. longitudinal reinforcements of tunnel; front section  
 30. longitudinal reinforcements of tunnel; rear section  
 31. shock absorber top mountings; front



32. longitudinal member; floor panel; rear section  
 33. rear longitudinal members; front section  
 34. rear suspension

35. crossmember front of spare wheel well  
 36. rear longitudinal members; rear section  
 37. inner and outer sills; remove plug

38. longitudinal members; rear section; remove plug  
 39. shock absorber top mountings; rear