

HYUNDAI EXCEL 1994-


VEHICLE ON THE FLOOR

			<ol style="list-style-type: none"> 1. engine bonnet; remove upholstery 2. bulkhead; detach panel 3. crossmember, upper
--	--	--	---

<ol style="list-style-type: none"> 4. front doors; rear section; remove rubber sealing 5. front doors; front section; drill and plug hole 	<ol style="list-style-type: none"> 6. 'A' posts; remove rubber sealing 7. rear doors; rear section; remove rubber sealing 8. rear doors; front section; drill and plug hole 	<ol style="list-style-type: none"> 9. 'B' posts; drill and plug hole; pull out and lock safety belt 10. 'C' posts; remove rubber sealing 	

			<ol style="list-style-type: none"> 11. tailgate; front section; remove rubber sealing 12. tailgate; left; right; detach panel 13. tailgate; rear section; remove rubber sealing 14. wheel arches; remove upholstery 15. crossmember, upper; remove upholstery


UNDERSIDE



16. front longitudinal members; front section
 17. crossmember, lower
 18. subframe
 19. front wheel suspension arms

20. front longitudinal members; rear section;
 remove rubber sealing
 21. tunnel reinforcement
 22. floor panel; reinforcements; front section
 23. sills; front; remove rubber sealing

24. sills; front section; remove rubber sealing
 25. reinforcements at front end of floor panel
 26. front wings; remove plastic insert



27. tunnel reinforcement
 28. crossmember front of fuel tank
 29. floor panel; reinforcements; rear section
 30. sills; rear; remove rubber sealing

31. sills; rear section; remove rubber sealing
 32. rear longitudinal members; front section
 33. rear suspension
 34. towing eye mounting

35. crossmember, lower
 36. rear longitudinal members; rear section
 37. rear wings; remove plastic insert