








KIA CLARUS 1996-




VEHICLE ON THE FLOOR




1. engine bonnet; remove upholstery
2. bulkhead; detach panel
3. crossmember, upper; detach panel
4. vertical reinforcements




5. front doors; double skin; remove upholstery
6. 'A' posts; drill and plug hole
7. rear doors; double skin; remove upholstery
8. 'B' posts; drill and plug hole; pull out and lock safety belt
9. 'C' posts; remove rubber sealing



10. tailgate; front section
11. tailgate; rear section
12. tailgate; left; right
13. crossmember, upper; remove upholstery



UNDERSIDE



14. crossmember, lower

15. front longitudinal members; front section

16. front longitudinal members; rear section

17. engine crossmember


18. subframe

19. floor panel; front section; reinforcements;
remove rubber sealing

20. floor panel; reinforcements; remove rubber
sealing

21. front wings; remove plastic insert

22. sills; front; detach panel; remove rubber
sealing



23. rear longitudinal members; front section

24. suspension arms; rear suspension

25. crossmember rear of fuel tank

26. rear longitudinal members; rear section

27. rear wings; remove plastic insert