









MAZDA 323 1997-







VEHICLE ON THE FLOOR



1. engine bonnet
2. bonnet hinge mountings
3. bulkhead; detach panel
4. crossmember, upper



5. front doors; rear section; drill and plug hole
6. 'A' posts; drill and plug hole
7. front doors; front section; drill and plug hole; loudspeaker!




8. 'C' posts; remove upholstery
9. crossmember, upper; detach panel

10. 'B' posts; wheel arches; remove upholstery; pull out and lock safety belt

11. tailgate; rear section; detach panel
12. tailgate; front section; remove rubber sealing


UNDERSIDE



13. crossmember, lower; detach panel
 14. longitudinal members; front; front section
 15. subframe

16. reinforcements at front end of floor panel
 17. floor panel; reinforcements; remove rubber sealing

18. tunnel reinforcements
 19. front wings; remove plastic insert



20. floor panel; reinforcements; remove rubber sealing
 21. longitudinal reinforcements of tunnel

22. sills; rear; remove rubber sealing
 23. longitudinal members; rear; front section

24. rear suspension; remove rubber sealing
 25. longitudinal members; rear; rear section
 26. rear wings; remove plastic insert