

# SAAB 9-5 1997-

## VEHICLE ON THE FLOOR


		<ol style="list-style-type: none"> <li>1. engine bonnet; remove upholstery</li> <li>2. bulkhead; detach panel</li> <li>3. longitudinal reinforcement in front wings; front section; remove rubber sealing</li> <li>4. longitudinal reinforcement in front wings; rear section</li> <li>5. crossmember, upper</li> </ol>

		<ol style="list-style-type: none"> <li>6. 'A' posts; drill and plug hole</li> <li>7. front doors; remove upholstery</li> <li>8. sills; front; detach panel</li> <li>9. 'B' posts; remove upholstery</li> <li>10. rear doors; remove upholstery</li> <li>11. sills; rear; detach panel</li> <li>12. 'C' posts; drill and plug hole</li> </ol>

			<ol style="list-style-type: none"> <li>13. tailgate; remove upholstery</li> <li>14. tailgate; remove grommet</li> <li>15. wheel arches; 'C' posts; detach upholstery</li> <li>16. crossmember, upper; detach panel</li> </ol>



## UNDERSIDE



17. crossmember, lower

18. front longitudinal members; front section

19. front longitudinal members; rear section

20. engine crossmember

21. crossmember


22. front wheel suspension arms

23. reinforcements at front end of floor panel

24. floor panel; front section

25. tunnel reinforcement

26. front wings; remove plastic insert



27. floor panel; rear section

28. rear longitudinal members; front section

29. sills

30. rear longitudinal members; rear section

31. longitudinal members

32. crossmember over rear suspension

33. rear suspension

34. crossmember, lower

35. crossmember front of spare wheel well

36. rear wings; remove plastic insert