


VOLKSWAGEN LT 1997-


VEHICLE ON THE FLOOR



1. engine bonnet; remove upholstery
2. crossmember, upper
3. wheel arches; detach upholstery; remove reservoir




4. 'A' posts; top section; remove grommet
5. 'A' posts; bottom section; hole at underside
6. front doors; front section
7. front doors; front section; drill and plug hole
8. front doors; rear section; drill and plug hole
9. 'B' posts; hole at underside
10. loading door posts; front
11. loading door posts; rear
12. 'C' posts; hole at underside
13. rear end of roof
14. doors; front section; drill and plug hole
15. doors; rear section; drill and plug hole



16. rear end of roof
17. 'D' posts
18. rear doors; drill and plug hole
19. 'D' posts; hole at underside


UNDERSIDE



- 20. crossmember, lower
- 21. front longitudinal members; front section
- 22. front longitudinal members; rear section; hole at top side
- 23. front longitudinal members

- 24. transversal reinforcement
- 25. suspension arms
- 26. gearbox mounting
- 27. transversal reinforcement
- 28. longitudinal members; front section

- 29. crossmember over fueltank
- 30. transversal reinforcement
- 31. sills; front section; 'A' posts; 'B' posts
- 32. front wings



- 33. crossmember rear of fuel tank
- 34. longitudinal members; rear section
- 35. sills; 'C' posts; remove rubber sealing
- 36. crossmember

- 37. strut top mountings; front section
- 38. rear longitudinal members; front section
- 39. rear longitudinal members
- 40. crossmember
- 41. 'D' posts; remove rubber sealing

- 42. strut top mountings; rear section
- 43. rear longitudinal members; rear section
- 44. crossmember, lower
- 45. rear wings